



### ORDER INSTRUCTIONS

**To order a complete set or a guide bar, please provide the following information:**

- Mortise dimensions: width (W) (corresponding to the thickness or width of the chain), length (L) and depth (D).
- Machines centre guide-sprockets "E" (if different from the standard one of 150 mm).
- Inner link chain.
- Thickness of the bearing.
- Make and model of mortise machine (if possible).
- Specify if the guide bars have to be with «CL» lubrication (connection for automatic oil pump) or «CI», with the Stauffer manual grease cup.

**To order a single chain, please provide the following information:**

- Width (or thickness) of the chain.
- Number of links that it is made up of.
- Chain pitch.
- Thickness of its inner link.

**To order sprockets and bar ends, please provide the following information:**

- Mortise width (W).
- Mortise length (L).
- Chain pitch.
- Thickness of the bearing.
- Number of teeth on sprocket

